

USB Software Update for THT 82

The following manual describes the procedure for a software update at your receiver via your PC and portable USB storage device.

Hardware Requirements:

- PC, Laptop or other operating system with USB 2.0 port. Other systems might require different procedures.
- External USB device formatted in FAT 32

Note: Please check/ensure that power consumption of your USB device is not higher than 5 V/500 mA. In case of higher power consumption, please use a corresponding line adapter before connecting to your receiver.

Procedure at your PC:

1. Connect an USB device to your USB port at the PC (or similar device) properly. Usually, your PC displays a message for a newfound/connected hardware (removable disk). If this is not the case directly you may need to wait for driver installation of this USB device.
2. Save the zipped file to the root directory of this connected USB device. Unpack the file there (Right mouse click: "Unpack here..." or double click and extract, then choose the root directory to save the file).
3. Now the .bin file from the downloaded package should be in the root directory of the connected USB device.
4. Remove the USB device from your PC by pressing the right mouse button at task bar to "Safely remove hardware" in order to avoid any problems.

Procedure at your Receiver:

Switch ON your receiver and connect the USB device with the software file (in the root directory) to the USB connector on the Y-cable at the receiver. After the USB device has been successfully detected, you can perform the software update according to the following steps:

1. Press **MENU** button to enter Main Menu. Select System with the ◀▶ buttons and use ▲▼ to select Software Update then press **OK** to open this menu.
2. Now select USB Upgrade with ▲▼ and press **OK**.
3. After the update file has been detected correctly and successfully, the filename will be displayed. Use ▲▼ to select it and press **OK** to start the update process.
4. Now the receiver will reboot to "Upgrading..." screen with blue background. Please wait patiently until the receiver finished!

NEVER disconnect the USB device from the receiver, the receiver from the main or switch OFF power during the update procedure. It can damage your receiver and warranty will void! As soon as the update has been finished, the receiver restarts automatically!