

USB Software Update for THT808

The following manual describes the procedure for a software update at your receiver via your PC and portable USB storage device.

Hardware Requirements:

- PC, Laptop or other operating system with USB 2.0 port. Other systems might require different procedures.
- External USB device formatted in FAT 32

Note: Please check/ensure that power consumption of your USB device is not higher than 5 V/800 mA. In case of higher power consumption, please use a corresponding line adapter before connecting to your receiver, otherwise your receiver could get damaged.

Procedure at your PC:

1. Connect an USB device to your USB port at the PC (or similar device) properly. Usually your PC displays a message for a new found/connected hardware (removable disk). If this is not the case directly you may need to wait for driver installation of this USB device.
2. Save the zipped file to the root directory of this connected USB device. Unpack the file there (right mouse click: "Unpack here..." or double click and extract, then choose the root directory to save the file).
3. Now the **.bin** from the downloaded package should be in the root directory of the connected USB device.
4. Remove the USB device from your PC by pressing the right mouse button at task bar to "Safely remove hardware" in order to avoid any problems.

Procedure at your Receiver:

Switch ON your receiver and connect the USB device with the software file (in the root directory) to the connector at the receiver. After the USB device has been successfully detected, you can perform the software update according to the following steps:

1. Press **MENU** button to enter Main Menu. Select *System* with the ◀▶ buttons and use ▲▼ to select *USB upgrade* then press **OK** to open this menu.
2. At *Upgrade Mode* select *App All* and then select the upgrade file in the list
3. Select *Start* and press **OK** to start update
4. Then you can see the update progress on screen. Please wait until the receiver finished and reboots.

NEVER disconnect the USB device from the receiver, the receiver from the main or switch OFF power during the update procedure. It can damage your receiver and warranty will void! As soon as the update has been finished, the receiver restarts automatically on the last watched channel!